


SHERWOOD SAFETY ARC FLASH UPPER BODY SIZE CHART

Sizes are in cm. If your measurement falls between sizes, order the next size up.

NOTE: Tolerance of ± 1.25 cm on all measurement values




Size (cm)	Jacket Length A	Coat Length B	Collar C	Shoulder D	Chest E	Sleeve F	Cuff G
S	80.0	124.5	52.1	49.5	116.8	59.7	30.5
M	81.3	124.5	53.3	52.1	121.9	61.0	33.0
L	82.6	127.0	54.6	53.3	127.0	62.2	33.0
XL	83.8	127.0	55.9	54.6	132.1	63.5	34.3
2XL	85.1	129.5	57.2	55.9	137.2	64.8	35.6
3XL	86.4	129.5	58.4	57.2	142.2	64.8	36.8
4XL	87.6	132.1	59.7	58.4	147.3	66.0	38.1
5XL	88.9	132.1	61.0	59.7	152.4	67.3	39.4

SHERWOOD SAFETY ARC FLASH LEG SIZE CHART

Sizes are in cm. If your measurement falls between sizes, order the next size up.

NOTE: Tolerance of ± 1.25 cm on all measurement values

- A Length
- B Waist
- C Hip
- D Crotch
- E Thigh
- F Bottom



Size (cm)	Length A	Waist B	Hip C	Crotch D	Thigh E	Bottom F
S	102.9	81.2 - 101.6	111.8	73.7	69.9	44.5
M	104.1	86.4 - 106.7	116.8	76.2	72.4	45.7
L	108.0	91.4 - 111.8	122.0	78.8	74.9	48.3
XL	109.2	96.5 - 116.8	127.0	81.3	76.2	48.3
2XL	110.5	101.6 - 121.9	132.1	83.8	78.7	48.3
3XL	111.8	106.7 - 127.0	137.2	86.4	81.3	49.5
4XL	113.0	111.8 - 132.1	142.2	88.9	83.8	50.8
5XL	114.3	116.8 - 137.2	147.3	91.4	86.4	52.1